

TRANSIENT ELECTROMAGNETICS





Quick Guide for Explorer Coils (3.0 m imes 3.0 m & 1.6 m imes 1.6 m)


## PRE-SURVEY PROCEDURE

## A. Check components

 Check all components are present and correct, see right, noting that the eight extension poles (bottom right) are only required for the 3.0m coils.

## **B.** Prepare the batteries

- Charge batteries using the supplied GroundTEM battery charger;
- Guidance notes in the lid provide information on checking battery status.



# **ASSEMBLY & START-UP PROCEDURE**

### A. Build frames (Step 1)

- Place central cross-pieces down, note the engraved "UP" instructions;
- 1.6m coils: insert four poles into each central cross-piece, with the strap buckles towards the free end of the poles;
- 3.0m coils: insert extension poles (without strap buckle) into the central cross-pieces, and push outer poles (with buckles) onto the extension poles; buckles on the outer poles should be towards the center.

# B. Connect carrying straps and handle (Step 2)

- Lay the carrying handles at the center of the frames;
- Pull straps along each pole, ensuring the coloured (grey & orange) clips on the straps match the coloured bands on the central cross-pieces;
- Clip the straps to the poles, and adjust lengths until frame hangs level.

# C. Attach Tx and Rx coils (Step 3)


- Lay the coils over the frames, matching the coloured corner pieces with the coloured bands on the straps and central cross-pieces;
- Insert the corner pieces of the coils into the end of the poles:
- The coils will be tight on the frames, so this stage can be difficult, especially in cold conditions; try to "roll" the corner-pieces into the end of the poles.

# D. Connect strain-relief cords (Step 4 & 5)


- Hook strain relief loops into the fastening on the central cross-pieces:
- Clip the sprung-loaded clips through the holes on the top corners of the instrument case when connecting the Tx and Rx lead-in cables.


### E. Power-on the instrument


- Press the silver power button on the instrument;
- Three green lights indicate that power is on the transmitter (Tx), power is on the receiver (Rx), and GPS signal is received (flashing light).



















# **MAKING A MEASUREMENT**









#### A. Connect to the GroundTEM instrument

- On your chosen device, connect to the GroundTEM Wi-Fi network (e.g. "GroundTEM0000");
- The Wi-Fi password is *GroundTEM* (case sensitive);
- Start the GroundTEM App (available for Android from Google Play / Guideline Geo website);
- Follow on-screen prompts if the device and instrument fail to connect.

0

0

# **B.** Check configuration

- On the Settings page, under Instrument Type, select "GroundTEM Explorer";
- This example is from an instrument with an active *Real-time Inversion* subscription.

# C. Choose an Explorer Coil measurement script

- Scripts are named according to transmitter / receiver loop size – select the correct one for the current configuration.

# D. Enter a project name, line / station numbers, and measurement duration

- The top box is for file management: it is possible to survey individual stations, along survey lines, within projects (note that separate projects must be used for different configurations / scripts);
- Select measurement duration then press *Play* button: 1 to 5 minutes are normally sufficient for Explorer surveys but, if data are coming in cleanly / consistently, it is possible to stop longer measurements early, without losing data.

#### E. Monitor the live results

- Decay / apparent resistivity curves can be inspected (swipe left/right to switch between the two displays), to ensure that they are smooth and stable between repetitions;
- Instrument temperature and output current can be checked using the monitoring bars.

#### F. Review real-time inversion results

- An inversion, showing an auto-processed resistivity model can be seen during measurement\*;
- If multiple stations have been collected in a line, swipe sideways to view a 2D profile of results.

## **FILE MANAGEMENT**

#### A. Install ABEM GroundTEM Connect

- Download the GroundTEM Connect software from the Guideline Geo webpages (use QR code on first page);
- After installing, right click on the GroundTEM Connect icon and tick "Run as Administrator".

# **B.** Downloading data

- Connect the PC to the GroundTEM Wi-Fi network (ID: GroundTEM#### Password: GroundTEM);
- Click on "Connect to Instrument" (if it fails, firstly check the Wi-Fi connection, then make sure that the GroundTEM Connect settings are correct (\*), try the "Default settings" button, if necessary);
- The left panel shows projects on the instrument, whilst the right panel shows the default download location;
- If the right panel is blank, refresh the view (5);
- Select the required projects in the left window and click on the "Copy" button, between the two windows;
- To change the download location, either add a new directory (□) or work up through existing directories (□ back);
- If the USF file (an industry standard format, compatible with all 1D inversion software) is corrupt or missing, use the "STB -> USF" button to generate a new one from the selected project folder.